

Installation & Assembly of Colonial Carriage Light

Items Needed:

- Adjustable Wrench
- Phillips Screwdriver
- Wire Cutters
- Step Ladder

Parts List:

- Fixture Body
- Top Fixture Cover
- Hardware Bag
- Washington/French Courtyard Post

Before Installation:

***WARNING:**

THE FOLLOWING INSTRUCTIONS MUST BE FOLLOWED WHEN INSTALLING THIS LIGHT FIXTURE IN ACCORDANCE WITH THE LOCAL CONSTRUCTION CODES IN YOUR AREA. FAILURE TO COMPLY WITH THESE REQUIREMENTS COULD LEAD TO ELECTRICAL SHOCK OR FIRE.

***WARNING:**

ALWAYS SHUT OFF POWER AT THE CIRCUIT BREAKER OR DISCONNECT FUSE WHEN INSTALLING OR REPAIRING THIS OR ANY OTHER ELECTRIC APPLIANCE. FAILURE TO DO SO MAY RESULT IN SEVERE INJURY OR EVEN DEATH.

- 1.) After post is installed, set fixture on top of post and note hole locations in the steel post insert (tenon).
- 2.) Remove fixture and expose the wiring. Twist the white wire with the white conduit wire (use wire nuts to secure connections).
- 3.) Twist together the black fixture wire with the black conduit wire (use wire nuts to secure connections).
- 4.) Tuck wires into steel post insert (tenon) and replace fixture onto tenon. Use provided screws to secure fixture to steel post tenon.
- 5.) Next, insert and twist light bulb into socket. Use 1 bulb. Type A, maximum 100W or less. DO NOT OVER LAMP.
- 6.) Place top cover on the fixture and secure into place from the bottom using the provided screws.
- 7.) Turn the power back on.

