

Optional Surface Mount Upgrade For Washington Post

Before Any Installation

- **WARNING:** Check with local utility companies for location of underground utility lines (electrical, gas, water, etc.)
- **CHECK** with your local postal authority for location and placement of mailbox posts.
- **Requires:** Customer supplied mounting bolts
Customer is responsible for concrete pad

The surface mount option was designed with the property developer in mind. With this upgrade, the concrete pads can be poured by the development's mason at the time the driveways and patios are being poured. When the concrete pad is poured, (4) bolts are placed into the wet concrete with threads exposed, placement is according to provided template. When you are ready to install your mailbox, simply place the fully assembled post over the (4) bolt threads, and spin on the lock nuts. Your post installation is complete.

